


## Braunston Village Hall Sound System – operating instructions

Our sound system has eight speakers around the walls of the main hall, with the amplifier and a wireless microphone receiver in a cabinet under the mantelpiece. The key to the cabinet will be provided with the main hall key; please make sure that you lock the cabinet after use.

The system is designed to be easy for anyone to play audio through the speakers using any device such as a mobile phone, ipad or laptop.

Remember that the hall is in a residential area, so please keep your sound volumes to a reasonable level in order not to disturb our neighbours.

### Amplifier controls



There are three ways to use the system; instructions for each are below:

1. Bluetooth from your iPhone, iPad or other device
2. Input lead from any device with a round 3.5mm socket
3. From a wireless microphone

### Bluetooth

Switch on the amplifier on the top rack of the cabinet; the power switch is on the right hand side.

Press the 'mode' button until 'Bluetooth' appears on the display; the mode button is on the left under the display panel

On your device, go to the Bluetooth menu and look for 'PRM amplifier'; select this to connect.

Once connected, start playing from your preferred app; the volume can be adjusted by the amplifier volume control and the volume control on your device.

When finished, press the 'mode' button again so that 'No device' is displayed.

Switch the amplifier off using the power switch.

Note that only one Bluetooth device can connect with the system at any time

### **Using an input lead**

Make sure that the amplifier power is switched **off**

Turn down the volume

Connect the blue lead with the round 3.5mm connector to your device.

Switch the amplifier power on.

Make sure that the display is showing 'No device'; if it isn't, press the mode button until it does.

Start playing from from your preferred app, and adjust the volume.

Make sure you switch off the power before disconnecting your device.

### **Using a wireless microphone**

The microphone and its receiver box is on the shelf under the main amplifier.

Switch on the Vonyx receiver box using the power button at the bottom right hand corner.

Switch the main amplifier power on

Switch on the microphone using the switch at the base of the mike.

Adjust the volume.

Switch all devices off after use.